

# Power failure panel

# UMPS



## Description

- **UMPS**, Uranos Manager Power Failure Panel, is used in connection with monitoring of point extracts type **Uranos Local Exhaust Guard** (ULEG), where **Uranos Manager Touch Panel** (UMTP) has been selected.
- In the event of a power failure on ULEG, the light and sound emit short flashes and beeps at intervals, via the rechargeable battery back-up in ULEG.

## Installation

- Flush-mounted installation:
  - Fits all FUGA 1 ½ module boxes.
- Exposed installation:
  - BASELINE/SOFTLINE 1 ½ module standard or panel base.
- Mounted on the corresponding RJ11 connector in ULEG.

## Colours

- Traffic White. RAL 9016.

## Material

- PVC-free, Halogen-free, complies with the RoHS directive.

## Technical data

### TAB-1: Power failure panel – UMPS

Panel R485	
Protocol	Modbus RTU
A	Data +
B	Data -
Baud rate	19,2k
Parity	Even
Data bits	8 bit
Stop bits	1
Power out	15VDC (9 VDC during backup), max. 0,1 mA